



GIR VA 15+ STI 72mm Cold Air Intake

Note:

TUNING IS REQUIRED WITH INSTALLATION OF COLD AIR INTAKE

Parts Included:

- GIR 72mm coated intake pipe with laser etched logo
- 2 x hose clamps
- Intake base plate
- Intake fender plate
- 2 x M6 bolts
- 45° silicon joiner
- Straight silicon joiner reducer
- BMC Air Filter



Tools Required:

- Phillips head screwdriver
- Flat head screwdriver
- 10mm spanner or 10mm socket and ratchet



Installation:

- Remove factory airbox
- Transfer air flow meter to new GIR intake pipe
- Install base plate into vehicle and attach air filter in guard
- Install guard plate upper using factory mounting locations along top and join using supplied M6 bolts to base plate
- Fit 45° silicon elbow, GIR intake pipe and straight silicon joiner between base plate and factory inlet pipe
- Reconnect air flow meter wiring

Final Install Pictures:

